

Air Brake Hose Fittings

Air Brake Hose Sleeve



Part No.	Size	Weight(g)	Fob Price
1490-6	3/8"		
1490-8	1/2"		

Air Brake Hose Nut



Part No.	Size	Weight(g)	Fob Price
1491-6	3/8"		
1491-8	1/2"		



Part No.	Size	Weight(g)	Fob Price
1492-6	3/8"		
1492-8	1/2"		

Air Brake Hose Guard Spring



Part No.	Size	Weight(g)	Fob Price
1494S-6	3/8"		
1494S-8	1/2"		

Air Brake Hose Connector Body



Part No.	Hose x Male	Weight(g)	Fob Price
1492B-6-4	3/8" x 1/4"		
1492B-6-6	3/8" x 3/8"		
1492B-6-8	3/8" x 1/2"		
1492B-8-6	1/2" x 3/8"		
1492B-8-8	1/2" x 1/2"		

Air Brake Hose Connector



Part No.	Size	Weight(g)	Fob Price
1492-6-4	3/8" x 1/4"		
1492-6-6	3/8" x 3/8"		
1492-6-8	3/8" x 1/2"		
1492-8-6	1/2" x 3/8"		
1492-8-8	1/2" x 1/2"		

Air Brake Hose Guard Connector



Part No.	Size	Weight(g)	Fob Price
1493-6-4	3/8" x 1/4"		
1493-6-6	3/8" x 3/8"		
1493-6-8	3/8" x 1/2"		
1493-8-6	1/2" x 3/8"		
1493-8-8	1/2" x 1/2"		

Air Brake Hose Connector



Part No.	Size	Weight(g)	Fob Price
1494S-6	3/8"		
1494S-8	1/2"		

Air Brake Hose Fittings

Bulkhead Couplings



Air Brake Hose Male Adapter



Part No.	Size
1495-2	1/8 FPT x 5/8-18 UNF x 1 1/2 Long
1495-4A	1/4 FPT x 3/4-16 UNF x 31/32Long
1495-4B	1/4 FPT x 3/4-16 UNF x 1 1/2 Long
1495-6	3/8 FPT x 1-14 UNF x 1 5/16Long
1495-8	1/2 FPT x 1 1/8-14 UNF x 1 1/2 Long

Part No.	Size
1501-12-2	3/4-20 Straight Thread x 1/4 MPT
1501-12-6	3/4-20 Straight Thread x 3/8 MPT
1501-14-6	7/8-20 Straight Thread x 3/8 MPT
1501-14-8	7/8-20 Straight Thread x 1/2 MPT

Air Brake Hose Guard Connector



Part No.	Flare x F	Weight(g)	Fob Price
1496-6-6	3/8" x 3/8"		
1496-8-8	1/2" x 1/2"		

Assembly instructions

1. Slide nut onto hose.
2. Slide sleeve onto hose with tapered edge toward fitting body (see example).
3. Bottom hose into fitting.
4. Tighten nut until it contacts body hex.

Note: When reassembling fitting, body and nut should be inspected. Only reuse if parts are in proper condition. Sleeves should never be reused.

